



Procedure of drainage of the system and the pipes of the water trucks

Although every truck is built in a different way, the basic principle to empty completely the system and the pipes of your water truck is the same.

The procedure is simple. There are valves of ball style (fig1) on the lower spots of the water system under the truck. You will find also under the heads of the jets (fig3). It's that simple, you open them and let the water flows through opening the ball valve. That's all! **Please note that several ball valves can be installed on your truck according to the number of the devices installed.** If the vehicle has a cannon installed, turn down the nozzle it shows in the FIG. 6. **Please let all the ball valves must remain open during the winter season including the ball valve in the strainer.**

Don't hesitate to contact Camions A & R Dubois Inc. for further information at
1-800-363-4631

FIG. 1



FIG. 2




FIG. 3




FIG. 4



FIG. 5



FIG. 6

